
















- D** Montageanleitung
- NL** Handleiding voor de montage
- TR** Montaj talimatı
- FR** Instructions de montage
- CZ** Montážní návod
- HU** Összeszerelési útmutató
- GB** Assembly instructions
- PL** Instrukcja montażu
- RU** Инструкция по монтажу
- IT** Istruzioni di montaggio
- RO** Instructiuni de asamblare
- SK** Montážny návod








A	B	C1	C2	C3	D
1	S504-0023	2071	596	16	5/5
2	S504-1029	2045	550	15	2/5
3	S504-1030	2045	550	15	2/5
4	S504-1031	2045	530	15	2/5
5	S504-2017	1800	550	15	3/5
6	S504-2018	1800	550	15	3/5
7	S205-312	580	530	16	1/5
8	S504-3013	579	510	15	1/5
9	S504-9004	2055	591	2,5	3/5
10	S504-9305	2055	1189	2,5	3/5
11	dr-1171	1171,	30	15	1/5
12	S504-3011	1174	530	22	1/5
13	S504-5706	445	100	6	1/5
14	S504-0024	2071	596	16	4/5
15	S504-7355	445	100	6,	1/5













2


3




2




3




4



5






6














7



8







9







10



11

**Pflegehinweis!**

Bitte nur mit einem Staubtuch (kein Microfasertuch) oder einem feuchten Lappen reinigen. KEINE scheuernden Putzmittel verwenden!

**Wskazówka dotycząca pielęgnacji!**

Proszę czyścić tylko suchą lub lekko wilgotną szmatką do kurzu. Nie używać żadnych środków szorstkich!

